AMP PART

POWER PWB

DECK PART

DECK MECHA

AC IN 230V

JK101 SPK. TML.

JK102 L AUX R

PN501 TO DECK MECHA. L R E

CN201A FROM FRONT PCB
1 PWRCLT
2 AMUTE
3 SCL
4 SDA
5 DI ⇨ TO TUNER PART
6 PLLCLK ⇨ TO TUNER PART
7 CE ⇨ TO TUNER PART
8 DO ⇨ TO TUNER PART
9 AMST ⇨ TO TUNER PART
10 FMST ⇨ TO TUNER PART
11 D GND

CN202A FROM FRONT PCB
1 RECH
2 RECF
3 SOL
4 MOTOR
5 MODE
6 HALL
7 HALF
8 DKBEAT
9 REC MUTE
10 REC BIAS
11 PB MUTE

PN801 TO CD PCB
1 CD L
2 GND
3 CD R
4 A+9.6V
5 D GND
6 D+9.6V
7 +5.6V

PN502 from DECK
1 REC SW(NO)
2 HALL OUT
3 SOL
4 HALF SW
5 GND
6 Vcc
7 MOTOR H
8 MOTOR L
9 COM
10 MODE SW
11 CrO2 SW
12
13 REC SW(NC)

CN203A TO FRONT PCB: P2, +5.6V, F1, PSW3, EQ IN, D GND, DECK KEY, RESET, VAL

PN204 TO DECK KEY PCB: GND, DECK KEY

IC101 GL4558(1/2)
IC102 7805
IC103 GL7809
IC108 GL7812
IC105 TDA2052
IC106 TDA2052
IC107 TDA7318
IC501 KIA6225S
IC502 BA3308
IC503 BA3126N

TO CHASSIS GND

PB MUTE
REC MUTE
REC BIAS
REC L
REC R
DKBEAT
CrO2