



Standard schematic diagrams

■ Main section


5
4
3
2
1




SHEET 2/6



ECO OPTION (E/B/EN/EV/EE)



SHEET 2/6



SHEET 4/6


- MAIN signal
- TUNER signal
- CD signal
- TAPE P.B. signal
- TAPE REC. signal

Parts are safety assurance parts. When replacing those parts make sure to use the specified one.

■ Amplifier section

5

SHEET 1/6



TO FCW2

4

SHEET 1/6



TO RW2

3

2

1

A

B

C

D


E

F

G


SHEET 2/6

2-3






CD section




■ Tuner section (Ver. B, E, EE, EV)

5
4
3
2
1




➡ FM/TUNER SIGNAL
➡➡ AM SIGNAL


■ Tuner section (EE Only)



■ Power transformer board



■ Head phone board



■ Eco board

