




The following symbols are shown on the schematic diagram.

	+B
	10V
	8V
	5V
	3.3V
	ACC
	RADIO(L,R)
	CD(L,R)
	AUDIO(L,R)