



SCHEMATIC DIAGRAM-1

A OPERATION CIRCUIT

NOTE:

The number which noted at the connectors on the schematic diagram as "SCHEMATIC DIAGRAM-1" or "SCHEMATIC DIAGRAM-2" indicates the schematic diagram serial number located on the left corner in the schematic diagram.






SCHEMATIC DIAGRAM-2

A OPERATION CIRCUIT


——— : POSITIVE VOLTAGE LINE ⇨ : FM SIGNAL LINE
 - - - : NEGATIVE VOLTAGE LINE ⇨ : AM SIGNAL LINE ⇨ : AUDIO SIGNAL LINE



To SOUND PROCESSOR (SH-EH580)

To TUNER UNIT on SCHEMATIC DIAGRAM-5/11,12

B MAIN CIRCUIT




B MAIN CIRCUIT

→ : POSITIVE VOLTAGE LINE

— ➔ — : NEGATIVE VOLTAGE LINE

➡ :AUDIO SIGNAL LINE







SCHEMATIC DIAGRAM-4

→ : POSITIVE VOLTAGE LINE - - - - - : NEGATIVE VOLTAGE LINE


D AC IN CIRCUIT




E POWER TRANSFORMER(A) CIRCUIT



F POWER TRANSFORMER(B) CIRCUIT



SA-EH580(EE,EG,EP) AC IN, POWER TRANSFORMER(A),(B) CIRCUIT DIAGRAM



H

G

F

E

D

C

B

A

AC IN
(230V 50Hz)

3

42

43

44

45

46

47

48

SCHEMATIC DIAGRAM-5
Z120 TUNER UNIT(RAN0005EM-2)

→ : POSITIVE VOLTAGE LINE

➡ :AM SIGNAL LINE

■▶ :AM SIGNAL LINE
■■▶ :AM OSC SIGNAL LINE

