


↗	Цепь	Адрес
1	Вх. ОС	=A10-XP2:1
3	Вх. пр.	=A10-XP2:3
4	Вых. пр.	=A10-XP2:4
5	Вых. пр.	=A10-XP2:5

←	Цепь	Адрес
1	+28В	=A9-XS3:1
2	+28В	=A9-XS3:2
4,5	-28В	=A9-XS3:4,5
6,7	-28В	=A9-XS3:6,7



- ▷ +28V
- ▷ +28V
- ▷ -28V
- ▷ -28V