




+6V - 6V powered by S0 from battery
 VBUS - 6V powered by S1, PD, CPU
 VPP - 6V powered by CPU after boot

