


TO TUNER AMP P.C. BOARD



SWITCHES:

P. C. BOARD (A)

S2: FWD/REV SWITCH FWD-REV

P. C. BOARD (B)

S3: TAPE/TUN SWITCH.....TAPE-TUNER

MISCELLANEOUS

S1:MUTE SWITCH.....ON-OFF


The underlined indicates switch position.


HEAD UNIT: EXA1163


TUNER AMP P.C. BOARD

TEST TAPE: 315Hz, 0dB

R495-0527







NOTE	
Q	Symbol indicates a resistor. No differentiation is made between chip resistors and discrete resistors.
+	Symbol indicates a capacitor. No differentiation is made between chip capacitors and discrete capacitors.
	Decimal points for resistor and capacitor fixed values are expressed as 2.2-2R2 0.022-0022

Decimal points for resistor and capacitor fixed values are expressed as

