



SCHEMATIC DIAGRAM-1

A DVD MODULE CIRCUIT




A DVD MODULE CIRCUIT




SA-HT840EB DVD MODULE CIRCUIT

A DVD MODULE CIRCUIT








B MAIN CIRCUIT


— :+B SIGNAL LINE - - - :B SIGNAL LINE DVD :DVD(VIDEO) SIGNAL LINE



SA-HT840EB MAIN CIRCUIT

B MAIN CIRCUIT

— :+B SIGNAL LINE ➡ :MAIN SIGNAL LINE




TO **E**
VOLUME
CIRCUIT
(CN6032)on
SCHEMATIC
DIAGRAM-8

TO **D**
FL CIRCUIT
(CN6008)on
SCHEMATIC
DIAGRAM-8

TO
ACTIVE
SUBWOOFER
UNIT
SB-WA840EB-S

D FL CIRCUIT



E VOLUME CIRCUIT

